TELL 0

CIRCUS CHARLIE OPTIONAL DIP SWITCH SETTINGS

A. Dip Switch No.1 (8P Dip Switch)

Credits

	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~				4				
Coin	Plays	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW3
n 1717111111111111111111111111111111111	Plays 1 2 3 4 5 6 7 1 3 5 1	SW1 Off On Off On Off Cn Off Cn Off	SW2 Off Off On Off On Off On Off	SW3 Off Off Off Off On On On Off Off Off	SW4 Off Off Off Off Off Off Off Off On On	SW5 Off On Off On Off On Off On Off	SW6 Off Off On Off Off On Off On Off	SW7 Off Off Off On On On Off Off	SW3 Off Off Off Off Off Off Off On On
1044	2 4 1 3 Play	On Off On Off On	On Off Off On On	Off On On On	0 n 0 n 0 n 0 n 0 n	ûn Off On ●ff On	On Off Off On On	0ff 0n 0n 0n 0n	0n 0n 0n 0n 0n

B: Dip Switch No.2 (8P Dip Switch)

1. Number of Clowns

Number	SWI	SW2
O 3 4 5 7	Off On Off On	Off Off On On

2. Game Type

Style	SW3	Players
Table	Off	1 cr 2 Players
Upright	On	Only 1 Player

3. Bonus Points Setting

First	And Every	SW4	SW5
O 20,000	70,000	Off	Off
30,000	80,000	On	Off

B. Dip Switch No.2 (continues)

4. Play Difficulty

Option	SW6	SW7
Easy	Off	Off
O Normal	On	Off
Hard	Off	On
Difficult	On	On

5. Audio Attraction

Sound Mode	SW8	
No Sound In Attract Mode O Sound In Attract Mode	Off On	

O Denotes Normal Settings





